

## **Before Door Installation**

### **Inspect the delivered door**

When your new door is delivered, it is important that you inspect the exterior condition of the product before signing for the delivery.

If, contrary to expectations, you discover any transport damage, this must be noted on the consignment note (proof of delivery) at the time of receipt. The driver must also sign to confirm that the delivery is damaged. The note does not need to be detailed, but it is required in order for the damage to be processed and resolved.

These delivery inspection rules also apply if the delivery is received by your installer or a family member. After delivery, you have four (4) days to report any other potential defects. However, the reseller can only accept returns if the door has not been installed. Therefore, always inspect the delivery carefully before installation.

### **Proper Storage of Your Door**

During storage, handling, and installation, the product must be protected from precipitation, ground moisture, and dirt. Doors, whether interior or exterior, must be handled with care to avoid damage.

If possible, it is recommended that your new doors are stored indoors in a heated, dry space with a minimum temperature of 18°C. Store the door upright on its edge (not laid flat).

Please note:

- The storage area must be well ventilated.
- Humidity levels must be kept low.
- Products must be placed upright on a level surface, at least 100 mm above floor level.
- Ensure that fittings or hardware do not damage other products or accessories.

### **During Door Installation**

To ensure warranty validity, it is essential that all installation instructions are followed carefully.

As a preventive measure for painted products, we recommend polishing the door leaf with standard automotive wax designed for metallic finishes (as this type of wax does not contain silicone).

All exterior wooden doors must be surface-treated immediately after installation using the oil supplied with the product upon delivery in order for the warranty to remain valid. Thereafter, the door must be maintained regularly, typically 1–2 times per year or as needed. Only then do the warranties apply as stated at delivery.

For more information, please refer to the section “Care and Maintenance Instructions.”

Doors and side panels made of untreated pine must be surface-treated with wood stain before installation (both door leaf and frame). This treatment must be repeated as required. Please note that untreated pine products must not be top-coated with opaque paint.

### **Take Care of Your Door**

A SnickarPer product is manufactured from high-quality materials. To maintain its finish over time, it requires care and maintenance—just like any valuable asset. Regular maintenance is also a condition for the warranty to remain valid.

### **Placement**

The installation environment plays a key role in determining the level of maintenance required for your door, gate, or side panel. In exposed locations, more frequent maintenance is required to protect against rain, wind, and sun. More detailed maintenance intervals can be found in SnickarPer’s care and maintenance instructions.

### **Installation, Adjustment, and Re-adjustment**

Over time, the door leaf may require re-adjustment. Below you will find installation instructions for exterior and interior doors.

Please note that the installation instructions must be followed carefully for the warranty to remain valid.